

---

# WIRELESS TRANSMISSION SYSTEM FOR IP HD CAMERA

## EXTERNAL TRANSMITTING-RECEIVING UNIT CDS-5IP

### Quick Installation Guide



---

## Copyright

Copyright © 2011 all rights reserved. No part of this publication may be reproduced, adapted, stored in a retrieval system, translated into any language, or transmitted in any form or by any means without the written permission of the supplier.

## About the Quick Installation Guide

This Quick Installation Guide is intended to guide professional installer to install the CDS-5IP. It covers procedures to assist you in avoiding unforeseen problems.

## Conventions



### **Warning:**

---

- This sign indicates a warning or caution that you have to abide.
- 



### **Note:**

---

- This sign indicates an important note that you must pay attention to.
- 
-

---

# Chapter 1 Introduction

## Introduction

CDS-5IP is a wireless transmission system designed to transmit audio / video in the 5GHz frequency band power of 1W (30dbi). The device transmits signals from IP cameras with high resolution (up to 5Mpixels). Built-in dual antenna 5GHz MIMO 2 x 16dBi allows signal transmission as standard to 2km, and the possibility of using fine-tuning function of the antenna provides high transmission quality even at varying distances. The additional two RP-SMA outputs give possibility to connect MIMO dual external antennas and thus significantly increase the operating range.

### CHARACTERISTICS

- stable high-quality HD transmission in the 5GHz band,
- 1W high radio power (30dbi)
- Works in the point-to-point and point-to-multipoint configuration
- OFDM radio modulation
- Max speed 300Mbps
- 64/128/152-bit transmission coding
- Integrated MIMO dual antenna 2x16dbi and R-SMA outputs for additional antennas
- link testing tool
- PoE 15-18VDC / 0,8 A
- Radio signal level indicator - LED indicators
- RF power control
- Works with all video resolutions - from VGA (640x480) by HD (1080p) to QXGA (2560x2048)

---

## Product Package

The product package you have received should contain the following items. If any of them are not included or damaged, please contact your local vendor for support.

- CDS-5IP - Wireless External Video Unit × 1
- Pole Mounting Ring × 2
- Power Cord & POE Injector × 1
- Product CD × 1

---

# Chapter 2 Preparation before Installation

This chapter describes safety precautions and product information you have to know and check before installing the CDS-5IP.

## Preparation before Installation

### Professional Installation Required

Please seek assistance from a professional installer who is well trained in the RF installation and knowledgeable in the local regulations.

### Safety Precautions

1. To keep you safe and install the hardware properly, please read and follow these safety precautions.
2. If you are installing the CDS-5IP - Wireless External Unit for the first time, for your safety as well as others', please seek assistance from a professional installer who has received safety training on the hazards involved.
3. Keep safety as well as performance in mind when selecting your installation site, especially where there are electric power and phone lines.
4. When installing the CDS-5IP, please note the following things:
  - ◆ Do not use a metal ladder;
  - ◆ Do not work on a wet or windy day;
  - ◆ Wear shoes with rubber soles and heels, rubber gloves, long sleeved shirt or jacket.
5. When the system is operational, avoid standing directly in front of it. Strong RF fields are present when the transmitter is on.

---

## Installation Precautions

To keep the CDS-5IP - Wireless External Unit well while you are installing it, please read and follow these installation precautions.

1. Users **MUST** use a proper and well-installed grounding and surge arrestor with the Wireless External Video Unit; otherwise, a random lightning could easily cause fatal damage to the unit. **EMD (Lightning) DAMAGE IS NOT COVERED UNDER WARRANTY.**
2. Users **MUST** use the "Power cord & POE Injector" shipped in the box with the CDS-5IP. Use of other options will likely cause damage to the unit.
3. Users **MUST** power off the CDS-5IP - Wireless External Video Unit first before connecting the external antenna to it. Do not switch from built-in antenna to the external antenna from WEB management without physically attaching the external antenna onto unit; otherwise, damage might be caused to the unit itself.

---

# Chapter 3 System Installation

## Connect up

1. The bottom of CDS-5IP - Wireless External Video Unit is a movable cover. Loosen the screw with a Philips screwdriver. Grab the cover and pull it back harder to take it out as the figure shown below.





Figure 1 Move the Cover

2. Plug a standard Ethernet cable into the RJ45 port labeled “LAN 1”. Do not plug the cable into the RJ45 port labeled “LAN 2”.



Figure 2 Cable Connection

The secondary Ethernet port (labeled LAN 2) is for IP camera or next CDS-5IP Unit video integration. To use it you need to enable the secondary port in advance before connecting with the IP camera from the CDS-5IP's Web Management as shown below.



3. Take out the power cord and POE injector from the gift box, and plug the power cord into the DC port of the POE injector as the below picture shows.



Figure 3 Connect to POE Injector

4. Put what in the Step.2 and Step.3 together by plugging the other side of the Ethernet cable in into the POE port of the POE injector When you finish the Step.4, the set will be like the following picture:



Figure 4 Plug the Ethernet cable to the RJ-45 jack of the injector

5. Press the black PWR button beside the LAN 1 Ethernet port.



6. Attach and fasten the removable cover to the bottom of the unit with the screw.




7. Power on the CDS-5IP - Wireless External Video Unit by plugging the power adapter to the power socket.

---


## Using the External Antenna

The CDS-5IP - Wireless External Video Unit provides two reverse SMA antenna connectors if you prefer to use the external antenna for your application instead of the built-in directional antenna, please follow the steps below.

1. Remove the two plugs as circled below:



2. Connect your external antenna to the SMA-type connectors at the bottom of the Wireless External Video Unit.



 **Warning:**

- Users **MUST** power off the CDS-5IP - Wireless External Video Unit first before connecting the external antenna to it. Do not switch from built-in antenna to the external antenna from WEB management without physically attaching the external antenna onto the unit; otherwise, damage might be caused to the unit itself.

---

Follow the steps described in **Connect Up** to finish the installation.

---

## Pole Mounting

1. Turn the Wireless External Video Unit over. Put the pole mounting rings through the middle hole of it. Note that you should unlock the pole mounting ring with a screw driver before putting it through the CDS-5IP as the following right picture shows.




Figure 5 Pole Mounting – Step 1

2. Mount the CDS-5IP - Wireless External Video Unit steadily to the pole by locking the pole mounting ring tightly. The mounting ring supports pole diameter 32mm to 70mm.




3. Now you have completed the hardware installation of the CDS-5IP - Wireless External Video Unit .

---

## Chapter 4 Configuration

Connect the CDS-5IP with your PC by an Ethernet cable plugging in LAN port of POE injector in one side and in LAN port of PC in the other side. Power on the CDS-5IP by POE from the supplied POE injector and press the black power button beside the LAN1 port.

1. Assign a static IP address to your PC which should be in the same network segment with the CDS-5IP. As the default IP address of the CDS-5IP is 192.168.1.1, you may choose from 192.168.1.2 to 192.168.1.254. Then click **OK**.



2. Open the web browser on your PC, key in the IP address (192.168.1.1) of the CDS-5IP in the address bar, and then press **Enter**.

3. Now, you will see the log-in page of the CDS-5IP. The default Name and Password are “camsat” and “camsat” respectively. Enter the password and then click **Login**.



**Name**   
**Password**

We'll elaborate the CDS-5IP - Wireless External Video Unit factory default settings. You can re-acquire these parameters by default. If necessary, please refer to the “**Restore Factory Default Settings**”.

Table 1 Factory Default Settings

Features		Factory Default Settings
Username		camsat
Password		camsat
Wireless Unit Name		CDS-5IP
Operating Mode		Video Bridge
Data Rate		Auto
LAN	IP Address	192.168.1.1
	Subnet Mask	255.255.255.0
	Gateway	0.0.0.0
	Primary DNS Server	0.0.0.0
	Secondary DNS Server	0.0.0.0
Spanning Tree		Enable
802.11 Mode		802.11a/n
Country/Region		European Union
Channel Number		5500 MHz (CH100)
SSID		CAMSAT
Broadcast SSID		Enable

HT Protect	Disable
Data Rate	Auto
Output Power	Full
Channel Mode	20MHz
WMM	Enabled
RTS Threshold (byte)	2346
Fragmentation Length (byte)	2346
Beacon Interval	100
DTIM Interval	1
Space in Meter	0
Flow Control by AP	Disable
Security	Open System
Encryption	None
Wireless Separation	Disable
Access Control	Disable

For users who use the CDS-5IP - Wireless External Video Unit for the first time, it is recommended that you begin configuration from “**Basic Settings**” in “**System**” shown below:

**camSAT** WIRELESS TRANSMISSION SYSTEM FOR IP HD CAMERAS  
**CDS-5IP** Logout

Status **System** Wireless Management Tools

Basic Settings »  
TCP/IP Settings  
Time Settings

### Basic Settings

Use this page to configure the basic parameters of device.

#### Device Settings

Device Name:  (max. 15 characters and no spaces)  
 Network Mode:   
 Ethernet 1 DataRate:   
 Ethernet 2 DataRate:   
 Country/Region:   
 Secondary RJ45 Power:  Enabled  Disabled  
 Spanning Tree:  Enabled  Disabled  
 STP Forward Delay:  (1~30 seconds)

#### GPS Coordinate Settings

Latitude:    "  
 Longitude:    "

---

- **TCP/IP Settings**

Open “**TCP/IP Settings**” in “**System**” as below to configure the parameters for LAN which connects to the LAN port of the CDS-5IP. In this page, users may change the settings for IP Address, Subnet Mask, and DHCP Server.





Figure 6 TCP/IP Settings (Bridge)

**Obtain IP Address Automatically:** If a DHCP server exists in your network, you can check this option, thus the CDS-5IP - Wireless External Video Unit is able to obtain IP settings automatically from that DHCP server.

Since the CDS-5IP covers “Video Bridge mode”, “Master mode” as well as “Slave mode”, the following steps are categorized for convenience reading to describe how to set each mode after successful log-in.

## Video Bridge Mode

1. Open “**Basic Settings**” in “**Wireless**”. From **Wireless Mode**, select “**Video Bridge**” and click “**Apply**” to save settings.




The screenshot shows the camSAT web interface for the CDS-5IP system. The top navigation bar includes Status, System, **Wireless**, Management, and Tools. The left sidebar lists settings categories: Basic Settings (selected), Profile Settings, Advanced Settings, Access Control, and WDS Settings. The main content area is titled "Wireless Basic Settings" and contains the following configuration options:

- Disable Wireless LAN Interface
- Wireless Mode: Video Bridge (dropdown), Site Survey (button)
- Frequency/Channel: 5500MHz (100) (dropdown)
- Extension Channel: None (dropdown)
- Channel Mode: 20 MHz (dropdown)
- Antenna:  Internal (16 dBi),  SMA Connector
- Maximum Output Power (per chain): 12 to 14 dBm (slider), 14 dBm (input)
- Data Rate: Auto (dropdown)
- Extension Channel Protection: None (dropdown)

Buttons for "Apply" and "Cancel" are located at the bottom of the form.

2. Go to “**WDS Settings**” in “**Wireless**”, input the MAC address of the remote bridge to “**Remote AP MAC Address 1**” field and click “**Apply**”;



The screenshot shows the camSAT web interface for the CDS-5IP system, specifically the "WDS Settings" page. The top navigation bar and left sidebar are the same as in the previous screenshot. The main content area is titled "WDS Settings" and includes the following configuration options:

- WDS Separation:  Enabled,  Disabled
- Local MAC Address: 00:19:70:00:fc:60 (input)
- Remote AP MAC Address 1: 00:19:70:00:fb:c5 (input)
- Remote AP MAC Address 2: (input)
- Remote AP MAC Address 3: (input)
- Remote AP MAC Address 4: (input)

Buttons for "Apply" and "Cancel" are located at the bottom of the form.



**Note:**

Bridge uses the WDS protocol that is not defined as the standard thus compatibility issues between equipment from different vendors may arise. Moreover, Tree or Star shape network topology should be used in all WDS use-cases (i.e. if MASTER 2 and MASTER3 are specified as the WDS peers of MASTER1, MASTER2 should not be specified as the WDS peer of MASTER3 and MASTER3 should not be specified as the WDS peer of MASTER2 in any case). Mesh and Ring network topologies are not supported by WDS and should be avoided in all the use cases.

3. Repeat the above procedures to configure the remote CDS-5IP.
4. Use ping to check whether the link between the two bridges is OK.
5. To get a better wireless connectivity, antenna alignment is strongly recommended after both bridges are installed long distance apart.
6. Open “**Antenna Alignment**” in **Tools**. Choose the remote peer and click on the “**Start**” button.

The screenshot shows the camSAT CDS-5IP web interface. The header includes the camSAT logo, the text "WIRELESS TRANSMISSION SYSTEM FOR IP HD CAMERAS CDS-5IP", and a "Logout" link. The navigation menu has tabs for Status, System, Wireless, Management, and Tools. The left sidebar contains links for System Log, Site Survey, Ping Watchdog, Data Rate Test, Antenna Alignment (selected), and Speed Test. The main content area is titled "Antenna Alignment" and contains the instruction "Use this page to align the antenna by link quality." Below this is a table with two columns: "Index" and "MAC Address". The table has one row with Index "1" and MAC Address "00:19:70:00:fb:c5". There are "Refresh" and "Stop" buttons. At the bottom, the following statistics are displayed: Signal Strength: -24 dBm, Current RSSI: -24 dBm, Transmit Packets: 267, and Receive Packets: 72.

Index	MAC Address
1	00:19:70:00:fb:c5

Refresh Stop

Signal Strength: -24 dBm  
Current RSSI: -24 dBm  
Transmit Packets: 267  
Receive Packets: 72

7. Wait about 5 seconds, the antenna alignment starts and performs alignment every one second.
8. Fix the local antenna and adjust the remote antenna elevation and horizontal direction. During the adjustment, observe “**Current RSSI**” and “**Signal Strength**” in local bridge. The value will refresh every 1 second. Fix the remote antenna when it reaches your expectation. Usually, RSSI between -50 to -70dBm indicates rather good signal strength.
9. Adjust the local antenna after fixing the remote one. During the adjustment, observe “**Current RSSI**” and “**Signal Strength**” in the remote bridge. Fix the local antenna when it reaches your expectation. Under MASTER/SLAVE mode where Antenna Alignment Tool is not available, another option is provided to check the signal strength towards the connecting MASTER/SLAVE. Open “**Connections**” in “**Status**” as below, and click “**Refresh**” to view the current signal strength of wireless connectivity. If the signal is not so good, align the antenna manually.

The screenshot displays the camSAT CDS-5IP web interface. The top navigation bar includes 'Status', 'System', 'Wireless', 'Management', and 'Tools'. The left sidebar contains a menu with 'Information', 'Connections', 'Statistics', 'ARP Table', 'Bridge Table', 'DHCP Clients', and 'Network Activities'. The main content area is titled 'Association List' and contains a table with the following data:

VAP Index	MAC Address	Signal Strength	Noise Floor	Connection Time	Last IP	Action
1	00:19:70:00:fb:c5	-24	-96	2011-8-1 16:06:53	192.168.1.2	---

Below the table is a 'Refresh' button. A note above the table states: 'This table shows the MAC Address, IP Address and RSSI for each associated device(s)'.

---

## Master Mode

1. Choose **Wireless > Basic Settings**. Then you will see the “**Basic Settings**” page. Here, you can set the parameters to optimize your application. Click “**Apply**” to save the parameters. In addition, for better coverage of the Master, you may also use external MIMO antennas; if so, remember to set the antenna setting from “Internal (16 dBi)” to “SMA Connector” after your external antennas are physically installed.


**Warning:** Do not switch from built-in antenna to the external antenna from WEB management without physically attaching the external antenna onto the CDS-5IP; otherwise, damage might be caused to the device itself.

The screenshot displays the web management interface for the CDS-5IP device. At the top, the logo for 'camSAT' is on the left, and the title 'WIRELESS TRANSMISSION SYSTEM FOR IP HD CAMERAS CDS-5IP' is centered. A 'Logout' link is on the right. Below the title is a navigation bar with tabs for 'Status', 'System', 'Wireless', 'Management', and 'Tools'. The 'Wireless' tab is selected. On the left side, there is a sidebar menu with options: 'Basic Settings >>', 'Profile Settings', 'Advanced Settings', 'Access Control', and 'WDS Settings'. The main content area is titled 'Wireless Basic Settings' and contains the following configuration options:

- Disable Wireless LAN Interface
- Wireless Mode: MASTER (dropdown menu) [Site Survey button]
- Wireless Network Name (SSID): CAMSAT (text input) [more... button]
- Broadcast SSID:  Enabled  Disabled
- HT protect:  Enabled  Disabled
- Frequency/Channel: 5500MHz (100) (dropdown menu)
- Extension Channel: None (dropdown menu)
- Channel Mode: 20 MHz (dropdown menu)
- Antenna:  Internal (16 dBi)  SMA Connector
- Maximum Output Power (per chain): 12 to 14 dBm (slider control, currently at 14 dBm)
- Data Rate: Auto (dropdown menu)
- Extension Channel Protection: None (dropdown menu)

At the bottom of the settings area are 'Apply' and 'Cancel' buttons.

2. If security is required, open **Wireless > Profile Setting** and enter “**VAP Profile 1 Settings**” as below. You may set the parameters like “Network Authentication” and “Data Encryption” for more secure network communication in your application. Click **Apply** to save the parameters.



## Slave Mode

1. Choose **Wireless > Basic Settings**. Then you will see the “**Basic Settings**” page. Choose “SLAVE” from Wireless Mode, and click “**Apply**” to save it. Feel free to change the other parameters to optimize your application before clicking “**Apply**”.

**Note:** For longer transmission of the CDS-5IP, you may also use an external antenna; if so, remember to set the antenna setting from “Internal (16 dBi)” to “SMA Connector” after your external antenna is successfully installed.

**Warning:** Do not switch from built-in antenna to the external antenna from WEB management without physically attaching the external antenna onto the CDS-5IP; otherwise, damage might be caused to the device itself.

2. Click the “**Site Survey**” button beside **SLAVE Mode**. It will scan all the available CDS-5IP within coverage. Select the one you prefer to connect to, and click **Selected** to establish the connection.

## Wireless Site Survey

This page provides tool to scan the wireless network. If any Access Point or IBSS is found, you could choose to connect it manually when client mode is enabled.

Select	SSID	Frequency/Channel	MAC Address	Wireless Mode	Signal Strength	Security
<input checked="" type="radio"/>	CAMSAT	5500MHz(100)	00:19:70:00:fb:c5	802.11A/N	-20	NONE

Selected Scan

3. If the MASTER you connect to require authentication or encryption keys, click **Profile Settings** in the left column, fill out the corresponding items, and click “**Apply**” for data encryption.

The screenshot shows the CAMSAT CDS-5IP web interface. At the top, there is a logo for CAMSAT and the text "WIRELESS TRANSMISSION SYSTEM FOR IP HD CAMERAS CDS-5IP". Below this is a navigation bar with tabs for Status, System, Wireless, Management, and Tools. The main content area is titled "Station Profile Settings" and is divided into two sections: Basic Settings and Security Settings. In the Basic Settings section, there are fields for Profile Name (set to Profile1), Wireless Network Name (SSID) (set to CAMSAT), and WMM Support (set to Enabled). In the Security Settings section, there are fields for Network Authentication (set to Open System), Data Encryption (set to Open System), Key Type, Default Tx Key, WEP Passphrase, and four Encryption Key fields. A Generate Keys button is located next to the Network Authentication dropdown menu.

## Master Repeater Mode

1. Choose **Wireless > Basic Settings**. Choose "**MASTER Repeater**" from Wireless Mode, and click **Apply** to save it. Feel free to change the other parameters to optimize your application before clicking **Apply**.

### Note:

- For longer transmission of the CDS-5IP, you may also use an external antenna; if so, remember to set the antenna setting from "Internal (16 dBi)" to "SMA Connector" after your external antenna is successfully installed, **otherwise do not switch to "SMA Connector)" without physically attaching the external antenna,** otherwise, damage might be caused to device itself.

**camSAT** WIRELESS TRANSMISSION SYSTEM FOR IP HD CAMERAS **CDS-5IP** Logout

Status System **Wireless** Management Tools

Basic Settings **Wireless Basic Settings**

Profile Settings

Advanced Settings

Access Control

WDS Settings

Use this page to configure the parameters for wireless LAN clients which may connect to your Access Point. Here you may change wireless mode as well as wireless network parameters.

**Disable Wireless LAN Interface**

Wireless Mode: MASTER Repeater Site Survey

Wireless Network Name(SSID): CAMSAT (more...)

Broadcast SSID:  Enabled  Disabled

HT protect:  Enabled  Disabled

Frequency/Channel: 5500MHz (100)

Extension Channel: None

Channel Mode: 20 MHz

Antenna:  Internal (16 dBi)  SMA Connector

Maximum Output Power (per chain): 14 dBm

Data Rate: Auto

Extension Channel Protection: None

Apply Cancel

2. To establish point-to-point bridge connection, please follow the procedures described in **Video Bridge Mode**. To connect the wireless client to the MASTER, please follow the procedures described in **SLAVE Mode**.

Congratulations! You have primarily completed configuration on the CDS-5IP and they can be put into operation. For more advanced configurations, please refer to the User manual.

---

## General terms and conditions of a warranty

### Camsat company gives a warranty of 24 months for transmission sets of the following series:

TCO 5807, CAM 5816, CDS 5021, CD04, CD06, CDS-5IP

1. In case of detecting incorrect work of a device, before giving the device to the service, it is necessary to make sure that everything was done in accordance with the instruction manual.
2. In case of giving or sending the faulty device to be repaired, it is indispensable to enclose a detailed description in the written form including faulty action of the device with taking into consideration work environment and the way in which they can be seen.
3. One can use the warranty if he shows the proof of purchase (a receipt) with the claimed device including the purchase date and a description of the damage.
4. The warranty repair includes only damages resulting from causes included in the sold device.
5. The warranty repair will be made in the shortest time possible not exceeding 14 days counting from the date of accepting the device to be repaired in the service. In case of a necessity to import parts, the repair date can be exceeded. After making the repair, the warranty period is exceeded by the time of repair.
6. The guarantor is not responsible for losing configuration settings of the device resulting from the repair of the device or its damage.
7. The guarantor can refuse making the warranty repair or completely renounce from the warranty in case of stating that seals on the devices or subsystems included in it are broken.
8. All remarks concerning the service and resulting from the warranty are made only in the service of the Camsat company.

